## **EPS OVERLAY - Concrete Floor**

## **Product Datasheet**

EPS Overlay requires a flat and level solid sub-floor for the installation to fully support the floor finish on top. The grooved foiled insulation panels are then laid onto the concreate sub-floor.

The panels are available in 25mm or 50mm, however can be manufactured per project to suit. The underfloor heating pipe slots into the pre-grooved insulation panels.

A screed board or timber flooring will be required on top of the insulation panels, then your finished floor can be applied.

