

EPS OVERLAY – Timber Floor

Product Datasheet

EPS Overlay requires a flat and level sub-floor for the installation to fully support the floor finish on top. The grooved foiled insulation panels are then laid onto the structural floor layer.

The panels are available in 25mm or 50mm, however can be manufactured per project to suit. The underfloor heating pipe slots into the pre-grooved insulation panels.

A screed board or timber flooring will be required on top of the insulation panels, then your finished floor can be applied.

